



Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

Spare parts: When ordering spare parts, please specify type of sprinkler and code number.

Code	Fig No.	No.	Description	Code	Fig No.	No.	Description	Code	Fig No.	No.	Description
	1	1	Body		028	1	Complete Head		55	2	Screws
	2	1	Flange		28	1	Head		56	4	Nuts
	3	1	Sphere Support Cap		29	1	Ring		57	2	Knobs
	04	1	Complete Ring		30	1	Washer		58	2	Counterweight
	5	1	O-Ring		31	1	Ring		59	4	Screws
	5a	4	Connector Stud Bolt		32	2	Spacers		60	6	Nuts
	6	1	U Ring		33	1	Support		61	1	Cap
	7	74	Spheres		34	1	Disc		62	1	Spring
	8	1	Brake		35	1	Lock Ring		63	1	Pivot
	9	2	Screws		036	1	Complete Lever		64	1	Pivot
	10	1	Sphere Support Cap		36	1	Lever		65	1	Body
	11	1	Brake		37	1	Clamp		066	1	Complete Clamp
	012	1	Complete Support		38	3	Screws		66	1	Clamp
	12	1	Support		39	1	Spring		67	2	Screws
	12b	1	Bushing		40	1	Pinion		67a	2	Nuts
	013	1	Complete Arm		41	1	Pipe		67b	2	Washers
	13	1	Arm		43	1	O-Ring		68	2	Screws
	14	1	Pivot		44	1	O-Ring		69	1	Ring
	14a	2	Nuts		45	1	Screw		70	4	Stud Bolt
	15	1	Spoon		46	6	Screws		70a	4	Nuts
	16	1	Nut		047	1	Complete Pivot		071	1	Complete Pivot
	17	1	Nozzle Lock Ring		47	1	Pivot		73	1	Nut
	18	6	Nozzles		48	1	Lever		74	1	Spring
	19	1	Nozzle O-Ring		48a	1	Spring		74a	1	Pin
	20	2	Bearings		49	1	Screw		74b	1	Washer
	21	2	Bearings		50	6	Nuts		75	1	Pivot
	22	1	Spacer		51	1	Pivot		75a	1	Nut
	23	1	Spacer		52	2	Nozzles		76	1	Flange
	24	1	Spacer		053	1	Complete Clamp		76a	6	Nuts
	25	2	Rings		53	1	Clamp		77	1	Packing
	26	1	Ring		54	1	Clamp		78	2	Rings
	27	1	Ring		54a	4	Screws		79	1	Cap

