IB International Pty Ltd
PO Box 5481 Manly Qld 4179
Ph: 07 3348 8300 Fax: 07 3348 8900
Mob: 0408 379 619 Web: www.ibinternational.com.au

Duplex



Data, weights and dimensions are not binding for the manufacturer, who reserves the right to bring changes as he sees fit.

Spare parts: *When ordering spare parts, please specify type of sprinkler and code number.*

Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description	Code	Fig No.	Qty	Description
142201kit	01	1	Sprinkler Body	142226b	26b	1	Locking Nut				
142202kit	02	1	Arm	142227	27	1	Screw				
142203	3	1	External Body	142227a	27a	1	Nut				
142204kit	04	1	Internal Body	142228	28	1	Pipe-Head				
142205a	5a	1	Cap Split Pin	142229	29	1	Secondary Nozzle				
142206	6	1	Spacer	140329	29a	1	Packing For Nozzle				
142208	8	1	Arm Spring	142230	30	1	Knob				
142209	9	1	Arm Dpring Cap	142230a	30a	1	Bush				
142210	10	1	Friction Spring	142231	31	1	Water Rectifier				
142210a	10a	1	Friction Spring Cover	142233	33	1	Principal Pipe				
142211	11	2	Vulk Washer								
142211a	11a	2	Teflon Washer								
142212	12	1	Inox Washer								
142213a	13a	1	Rubber Washer								
142214	14	5	Main Nozzle								
142214a	14a	1	Nozzle O-Ring								
142215kit	015	1	Complete Principal Jet								
142215	15	1	Jet Breaker								
141816	16	1	Jet Breaker Screw								
141837	16a	1	Jet Breaker Spring								
141437	17	1	Nozzle Lock Ring								
142219kit	019	1	Complete Secondary Jet								
142219	19	1	Secondary Jet Breaker								
142220	20	1	Screw								
142220a	20a	1	Locking Nut								
141816	22	1	Secondary Jet Breaker								
141837	23	1	Spring Jet Breaker Screw								
142226	26	1	Wedge								
142226a	26a	1	Wedge Shaft								